2. Utility connection

2.1 Electrical power

WARNING



Turn off the power supply from the factory before starting connects the power lines.

Turn the power off the machine during connecting the utilities to avoid electric shock.

Failure to observe the warning could cause of serious injuries to human body and damage/performance decrement of the equipment.

- Rating: Single-phase, AC 100V +/- 5%, 50/60Hz

- Power consumption: 1.5 kVA



(1) Turn off the [MAIN POWER] switch.



(2) Connect the power source to the machine shown left photo, or connect the attached plug to the outlet in the factory.

The main power connector is at the lower right side of the machine.